



DayGlo

In Partnership With



Product Information

USA: 200 Main Ave., Elmwood Park, NJ 07407 | (201) 793-8700 | www.grantinc.com

Product: BLUE FROST EYE SHADOW

Formula Code: G6604-401.07

Phase	Ingredients	INCI	%
A	ORANGE BLOSSOM WATER	Citrus Aurantium Amara Flower Water	15.300
	ARISTOFLEX VELVET	Polyacrylate Crosspolymer-11	0.400
	TWEEN 20	Polysorbate 20	1.000
	BOSWELLIA SERRATA BT*	Water & Boswellia Serrata Extract & Phenoxyethanol & Sodium Benzoate	2.000
	GLYCERIN	Glycerin	3.000
	BUTYLENE GLYCOL	Butylene Glycol	3.000
	ALCOHOL DENATURED	Alcohol Denat.	10.000
	JEECID E CAP-5	Phenoxyethanol & Caprylyl Glycol & Potassium Sorbate & Water & Hexylene Glycol	1.000
	GRANPOWDER QSC	Polymethylsilsesquioxane/Silica Crosspolymer	5.000
	PLANTAREN 2000 N	Decyl Glucoside	0.300
B	GRANRESIN SIW-MQIZ	Isododecane & Trimethylsiloxysilicate & Water & Propanediol & Decyl Glucoside	25.000
	COCONUT OIL	Cocos Nucifera (Coconut) Oil	1.000
	GRANSURF 67	PEG-10 Dimethicone	1.000
C	ELARA HORIZON BLUE EL-37	Norbornanediamine/Resorcinol Diglycidyl Ether Crosspolymer & Aluminum Hydroxide & Blue 1 (CI 42090)	10.000
	TIMIRON SUPER SILVER	Mica & Titanium Dioxide (CI 77891)	14.000
	DRY FLO PC	Aluminum Starch Octenylsuccinate	8.000

Formula Total: 100.000

Procedure

1. Weigh Phase A in the main kettle equipped with side sweep. Mix well until uniform.
2. Weigh Phase B in a side kettle and mix well. Heat to 50-55 C.
3. Add Phase B to Phase A. Mix well until uniform.
4. Add each ingredient consecutively from Phase C. Mix well after each addition and continue mixing until uniform.

*BCR (www.BCRingredients.com)

Non-Warranty: We offer our products in good faith, but without guarantee as conditions and methods of application are beyond our control. User must determine suitability and compatibility before adopting them on a commercial scale.



In Partnership With



Product Information

USA: 100 Main Ave., Elmwood Park, NJ 07007 | (201) 793-8700 | www.grantinc.com

Product: STRAWBERRY SHOWER GEL

Formula Code: G61526-427.01

Phase	Ingredients	INCI	%
A	DEIONIZED WATER	Water	42.920
	BIOWAVE BCR*	Water & Propanediol & Polyglutamic Acid & Phenoxyethanol	2.000
	YOUTH 360 BCR*	Water & Boswellia Serrata Extract & Centella Asiatica Extract & Betula Alba Bark Extract & Polygonum Cuspidatum Root Extract & Phenoxyethanol & Sodium Benzoate	2.000
	JEECOL SA-21	Stearth-21	2.000
	DIOCIDE	Caprylyl Glycol & Phenoxyethanol & Hexylene Glycol	1.000
B	CARBOPOL ULTREZ 21 POLYMER	Acrylates/C10-30 Alkyl Acrylate Crosspolymer	0.750
C	PROTERIC CAB-LC	Cocamidopropyl Betaine	7.500
	ISELUX SFS-SB	Water & Sodium Lauroyl Methyl Isethionate & Cocamidopropyl Betaine & Sodium Cocoyl Isethionate & Sodium Methyl Oleoyl Taurate	25.000
	RITA CA	Cetyl Alcohol	3.500
	GRANSIL VX-419	Bis-PEG-12 Dimethicone	3.000
	GRANPOWDER QSC	Polymethylsilsesquioxane/Silica Crosspolymer	3.000
	JEECHEM GMS-450	Glyceryl Stearate	1.500
D	CETIOL LC	Coco-Caprylate/Caprate	3.000
	ELARA ROCKET RED EL-13	Norbornanediamine/Resorcinol Diglycidyl Ether Crosspolymer & Aluminum Hydroxide & Red 28 (CI 45410) & Orange 5 (CI 45370)	0.780
	ELARA BLAZE ORANGE EL-15	Norbornanediamine/Resorcinol Diglycidyl Ether Crosspolymer & Aluminum Hydroxide & Yellow 10 (CI 47005) & Red 28 (CI 45410) & Red 22 (CI 45380)	1.000
D	TRIS AMINO	Tromethamine	0.750
E	STRAWBERRY WS FRAGRANCE, ORC1403533	Fragrance	0.300

Formula Total: 100.000

Procedure

1. Weigh Phase A in the main kettle equipped with a propeller mixer.
2. Sprinkle Phase B into Phase A and mix well until dispersed. Then, heat 65-70C.
3. In a side kettle, weigh Phase C. Heat to 70-75C.
4. In a side kettle, pre-mix Phase D. Add to Phase C.
5. When at proper temperature, add Phase CD to Phase AB. Mix well until uniform.
6. Add Phase D to Phase ABCD. Mix until uniform.
7. Add Phase E to Phase ABCDE. Mix until uniform.
8. Cool to room temperature with slow side sweep mixing.

*BCR (www.BCRingredients.com)

Non-Warranty: We offer our products in good faith, but without guarantee as conditions and methods of application are beyond our control. User must determine suitability and compatibility before adopting them on a commercial scale.



In Partnership With



Product Information

USA: 100 Main Ave., Elmwood Park, NJ 07607 | (201) 793-8700 | www.grantinc.com

Product: **ELECTRIC PINK LIP GLOSS**

Formula Code: **G106-431.01**

Phase	Ingredients	INCI	%
A	GRANSIL VX-401	Stearoxymethicone/Dimethicone Copolymer	18.000
	INDOPOL H-100	Polybutene	30.000
	EUTANOL G	Octyldodecanol	19.000
	GRANSIL EPSQ	Dimethicone/Divinyldimethicone/Silsesquioxane Crosspolymer	6.500
	PERFORMALENE 400	Polyethylene	4.500
	POLYETHYLENE		
	DERMOL 99	Isononyl Isononanoate	1.800
	SQUALANE	Squalane	0.900
	PROTACHEM GMS-D	Glyceryl Stearate SE	1.900
	ALCOLEC BS	Lecithin	0.400
	ELARA ROCKET RED EL-13	Norbormanediamine/Resorcinol Diglycidyl Ether Crosspolymer & Aluminum Hydroxide & Red 28 (CI 45410) & Orange 5 (CI 45370)	14.200
	ALT-WHITE TSR	Titanium Dioxide (CI 77891) & Aluminum Hydroxide & Triethoxycaprylylsilane	2.800

Formula Total: 100.000

Procedure

1. Weigh Phase A in the main kettle equipped with homogenizer. Heat to 85-90C.. Mix until uniform.
2. Pour into containers at 70-75C.

Non-Warranty: We offer our products in good faith, but without guarantee as conditions and methods of application are beyond our control. User must determine suitability and compatibility before adopting them on a commercial scale.



DayGlo®

In Partnership With



Product Information

USA: 100 Main Ave., Elmwood Park, NJ 07607 | (201) 793-8700 | www.grantinc.com

Product: **NEON PINK LIP GLOSS**

Formula Code: **G106-428.01**

Phase	Ingredients	INCI	%
A	GRANSIL VX-401	Stearoxymethicone/Dimethicone Copolymer	18.000
	INDOPOL H-100	Polybutene	30.000
	EUTANOL G	Octyldodecanol	19.000
	GRANSIL EPSQ	Dimethicone/Divinyldimethicone/Silsesquioxane Crosspolymer	6.500
	PERFORMALENE 400	Polyethylene	4.500
	POLYETHYLENE		
	DERMOL 99	Isononyl Isononanoate	1.800
	SQUALANE	Squalane	0.900
	PROTACHEM GMS-D	Glyceryl Stearate SE	1.900
	ALCOLEC BS	Lecithin	0.400
	ELARA AURORA PINK EL-11	Norbormanediamine/Rescorcinol Diglycidyl Ether Crosspolymer & Aluminum Hydroxide & Red 28 (CI 45410) & Red 22 (CI 45380)	14.200
	ALT-WHITE TSR	Titanium Dioxide (CI 77891) & Aluminum Hydroxide & Triethoxycaprylylsilane	2.800

Formula Total: 100.000

Procedure

1. Weigh Phase A in the main kettle equipped with homogenizer. Heat to 85-90C.. Mix until uniform.
2. Pour into containers at 70-75C.

Non-Warranty: We offer our products in good faith, but without guarantee as conditions and methods of application are beyond our control. User must determine suitability and compatibility before adopting them on a commercial scale.



DayGlo®

In Partnership With



Product Information

USA: 100 Main Ave., Elmwood Park, NJ 07007 | (201) 793-8700 | www.grantinc.com

Product: **PASSION RED LIP COLOR**

Formula Code: **G6366-3154.02**

Phase	Ingredients	INCI	%
A	JEECHEM CTG	Caprylic/Capric Triglyceride	29.000
	COCONUT OIL	Cocos Nucifera (Coconut) Oil	10.000
	GRANSIL VX-418	Bis-Stearyl Dimethicone	8.000
	RITA SAO	Prunus Amygdalus Dulcis (Sweet Almond) Oil	5.000
	PHYTOLANE LS	Olive Squalane	7.000
	SHEA BUTTER	Butyrospermum Parkii Butter	7.000
	REFINED CANDELILLA WAX MD-21	Euphorbia Cerifera (Candelilla) Wax	1.000
	PERFORMALENE 400	Polyethylene	3.000
	POLYETHYLENE		
	BENTONE GEL EUG V	Octyldodecanol & Disteardimonium Hectorite & Propylene Carbonate	7.000
	VITAMIN E ACETATE	Tocopheryl Acetate	1.000
	ELARA ROCKET RED EL-13	Norbornanediimine/Resorcinol Diglycidyl Ether Crosspolymer & Aluminum Hydroxide & Red 28 (CI 45410) & Orange 5 (CI 45370)	15.000
	CLOISONNE VIVID RED 450	Mica & Iron Oxides (CI 77491) & Titanium Dioxide (CI 77891) & Silica	3.000
	DHCB		
B	NAT VANILLA MINT FL, UA6611	Flavor	4.000

Formula Total: 100.000

Procedure

1. Weigh Phase A in the main kettle equipped with marine type propeller.
2. Heat to 85-90C and mix until completely uniform..
3. Cool to 70C and add Phase B. Mix until uniform.
4. Pour samples.

Non-Warranty: We offer our products in good faith, but without guarantee as conditions and methods of application are beyond our control. User must determine suitability and compatibility before adopting them on a commercial scale.



DayGlo®

In Partnership With



Product Information

USA: 100 Main Ave., Elmwood Park, NJ 07007 | (201) 793-8700 | www.grantinc.com

Product: LAVA PINK LIP COLOR

Formula Code: G6366-430.01

Phase	Ingredients	INCI	%
A	JEECHEM CTG	Caprylic/Capric Triglyceride	29.000
	COCONUT OIL	Cocos Nucifera (Coconut) Oil	10.000
	GRANSIL VX-418	Bis-Stearyl Dimethicone	8.000
	RITA SAO	Prunus Amygdalus Dulcis (Sweet Almond) Oil	5.000
	PHYTOLANE LS	Olive Squalane	7.000
	SHEA BUTTER	Butyrospermum Parkii Butter	7.000
	REFINED CANDELILLA WAX MD-21	Euphorbia Cerifera (Candelilla) Wax	1.000
	PERFORMALENE 400	Polyethylene	3.000
	POLYETHYLENE		
	BENTONE GEL EUG V	Octyldodecanol & Distearidimonium Hectorite & Propylene Carbonate	7.000
	VITAMIN E ACETATE	Tocopheryl Acetate	1.000
	ELARA AURORA PINK EL-11	Norbornanediimine/Rescorcinol Diglycidyl Ether Crosspolymer & Aluminum Hydroxide & Red 28 (CI 45410) & Red 22 (CI 45380)	13.500
	DUOCROME YR 422C	Mica & Titanium Dioxide (CI 77891) & Iron Oxides (CI 77492)	3.000
	REFLECKS DIMENSIONS GLITTERING RED G430S	Calcium Sodium Borosilicate & Titanium Dioxide (CI 77891)	1.500
B	NAT VANILLA MINT FL, UA6611	Flavor	4.000

Formula Total: 100.000

Procedure

1. Weigh Phase A in the main kettle equipped with marine type propeller.
2. Heat to 85-90C and mix until completely uniform..
3. Cool to 70C and add Phase B. Mix until uniform.
4. Pour samples.

Non-Warranty: We offer our products in good faith, but without guarantee as conditions and methods of application are beyond our control. User must determine suitability and compatibility before adopting them on a commercial scale.



In Partnership With



Product Information

USA: 100 Main Ave., Elmwood Park, NJ 07607 | (201) 793-8700 | www.grantinc.com

Product: SUMMER SKY EYESHADOW

Formula Code: G6916-3155.01

Phase	Ingredients	INCI	%
A	GRANRESIN MQI-T50	Isododecane & Polymethylsilsesquioxane/Trimethylsiloxysilicate	27.000
	GRANRESIN PHQ-FLUID	Polyphenylsilsesquioxane/Trimethylsiloxysilicate & Dimethicone	10.000
	BENTONE GEL ISD V	Isododecane & Disteardimonium Hectorite & Propylene Carbonate	13.700
	GRANSIL PC-12	Isododecane & Polysilicone-11	10.200
	PARAFFIN WAX 140/145	Paraffin	4.000
	WHITE BEESWAX NF	Beeswax	2.000
	SYNCROWAX HRC	Tribehenin	1.000
	JEENATE 3H	Polyethylene	1.800
	DRY FLO PC	Aluminum Starch Octenylsuccinate	3.000
	AEROSIL 200	Silica	0.300
SILVER 2800	Mica	10.000	
B	GRANPOWDER EDC-600	Divinyldimethicone/Dimethicone/Phenylsilsesquioxane Crosspolymer	5.000
	RON TI-12	Titanium Dioxide (CI 77891)	2.000
	ELARA HORIZON BLUE EL-37	Norbornanediamine/Resorcinol Diglycidyl Ether Crosspolymer & Aluminum Hydroxide & Blue 1 (CI 42090)	10.000

Formula Total: 100.000

Procedure

1. Weigh Phase A in the main kettle equipped with a propeller mixer. Heat to 80-85 C and mix for 15-20 minutes.
2. Micro-pulverize Phase B. Add to Phase A and mix well until uniform.
3. Cool batch to room temperature using side sweep agitation.

Non-Warranty: We offer our products in good faith, but without guarantee as conditions and methods of application are beyond our control. User must determine suitability and compatibility before adopting them on a commercial scale.



In Partnership With



Product Information

USA: 100 Main Ave., Elmwood Park, NJ 07607 | (201) 793-8700 | www.grantinc.com

Product: GRAPEFRUIT GLOW MASK

Formula Code: G6791-404.03

Phase	Ingredients	INCI	%
A	DEIONIZED WATER	Water	64.700
	NATROSOL 250 HHR, 2% AQ SOL.	Water & Hydroxyethylcellulose	5.000
	BUTYLENE GLYCOL	Butylene Glycol	5.000
	TWEEN 20	Polysorbate 20	0.200
	PLANTAREN 2000 N	Decyl Glucoside	0.200
	TRIS AMINO	Tromethamine	0.200
	PELEMOL G 7A	Glycereth-7 Triacetate	3.500
	JEECIDE CAP-5	Phenoxyethanol & Caprylyl Glycol & Potassium Sorbate & Water & Hexylene Glycol	1.000
	GRANPOWDER QSC	Polymethylsilsesquioxane/Silica Crosspolymer	5.000
B	GRANSIL SIW-038	Dimethicone & Polysilicone-11 & Butyrospermum Parkii (Shea) Butter & Water & Glycerin & Decyl Glucoside	10.000
	RHEOSOL AVH	Sodium Polyacrylate & Ethylhexyl Stearate & Trideceth-6	2.300
C	ELARA BLAZE ORANGE EL-15	Norbornanediamine/Resorcinol Diglycidyl Ether Crosspolymer & Aluminum Hydroxide & Yellow 10 (CI 47005) & Red 28 (CI 45410) & Red 22 (CI 45380)	0.750
	GLYCERIN	Glycerin	2.000
D	GRAPEFRUIT EO	Citrus Grandis (Grapefruit) Peel Oil	0.150
			Formula Total: 100.000

Procedure

1. Weigh Phase A in the main kettle equipped with side sweep agitation. Mix well.
2. Weigh Phase B in a side kettle in a side kettle and slowly add to Phase A.
3. In a side kettle, mix Phase C until uniform. Add to Phase AB and mix well.
4. Add Phase D and mix until uniform.

Non-Warranty: We offer our products in good faith, but without guarantee as conditions and methods of application are beyond our control. User must determine suitability and compatibility before adopting them on a commercial scale.



DayGlo®

In Partnership With



Product Information

USA: 100 Main Ave., Elmwood Park, NJ 07607 | (201) 793-8700 | www.grantinc.com

Product: LUMINOUS LAVENDER MASK

Formula Code: G6791-403.03

Phase	Ingredients	INCI	%
A	DEIONIZED WATER	Water	64.700
	NATROSOL 250 HHR, 2% AQ SOL.	Water & Hydroxyethylcellulose	5.000
	BUTYLENE GLYCOL	Butylene Glycol	5.000
	TWEEN 20	Polysorbate 20	0.200
	PLANTAREN 2000 N	Decyl Glucoside	0.200
	TRIS AMINO	Tromethamine	0.200
	PELEMOL G 7A	Glycereth-7 Triacetate	3.500
	JEECIDE CAP-5	Phenoxyethanol & Caprylyl Glycol & Potassium Sorbate & Water & Hexylene Glycol	1.000
	GRANPOWDER QSC	Polymethylsilsesquioxane/Silica Crosspolymer	5.000
B	GRANSIL SIW-038	Dimethicone & Polysilicone-11 & Butyrospermum Parkii (Shea) Butter & Water & Glycerin & Decyl Glucoside	10.000
	RHEOSOL AVH	Sodium Polyacrylate & Ethylhexyl Stearate & Trideceth-6	2.300
C	ELARA ULTRA VIOLET EL-20	Norbormanediamine/Resorcinol Diglycidyl Ether Crosspolymer & Aluminum Hydroxide & Violet 2 (CI 60730) & Red 28 (CI 45410)	0.750
	GLYCERIN	Glycerin	2.000
D	LAVENDER 40/42 OIL	Lavandula Hybrida Oil	0.150
			Formula Total: 100.000

Procedure

1. Weigh Phase A in the main kettle equipped with side sweep agitation. Mix well.
2. Weigh Phase B in a side kettle in a side kettle and slowly add to Phase A.
3. In a side kettle, mix Phase C until uniform. Add to Phase AB and mix well.
4. Add Phase D and mix until uniform.

Non-Warranty: We offer our products in good faith, but without guarantee as conditions and methods of application are beyond our control. User must determine suitability and compatibility before adopting them on a commercial scale.